




MY シリーズ



MY PN119 プラグ

MY SR119 ソケット

種別 記号	L1	L2	L3	L4	L5	L6	L7	D1	D2	D3	D4	D5	D6	D7
2芯	163	102	84	38	31	117	27	29	27	55	31	25	29	31
5芯	166	105	84	38	34	120	31	33	41	59	35	29	33	35
7芯	168	107	84	38	36	121	34	36	44	62	38	32	36	38
12芯	171	110	84	38	41	124	41	43	51	69	38	39	43	45
19芯	176	115	84	38	46	130	48	50	59	76	52	46	50	52
27芯	178	117	84	38	52	131	55	58	68	85	61	54	58	61